



1. Please use the grease designated by Trident drive Harmonic Reducer installation note (MF-2 or MF-3)
2. The size with \* in the figure is the reference size for installation, please follow the installation size requirements;
3. For the details of the size, please use the delivery specification drawing to confirm



MODEL	U	T	W
Wave generator-A $\phi 8$	$\phi 8H7$	$9.4^{\pm 0.1}$	3P9
Wave generator-A $\phi 11$	$\phi 11H7$	$12.8^{\pm 0.1}$	4P9
Wave generator-A $\phi 14$	$\phi 14H7$	$16.3^{\pm 0.1}$	5P9

**NOT FOR PUBLICATION**  
 THE REPRODUCTION, DISTRIBUTION AND UTILIZATION OF THIS DOCUMENT AS WELL AS THE COMMUNICATION OF ITS CONTENTS TO OTHERS WITHOUT EXPRESS AUTHORIZATION IS PROHIBITED. OFFENDERS WILL BE HELD LIABLE FOR THE PAYMENT OF DAMAGES. ALL RIGHTS RESERVED IN THE EVENT OF THE GRANT OF A PATENT. UTILITY MODEL OR DESIGN

Title  
**TRIDENT DRIVE HARMONIC REDUCER**

Part No  
**MHT-20-XX-U-I**

CAD DRAWN - NOT TO BE MODIFIED BY HAND ALL DIMENSIONS IN MM